



















213 Nähmaschine / Sewing Machine




LEVEL



- 4x 1
- 1x 2
- 2x 3
- 2x 4
- 2x 5
- 1x 2
- 2x 5
- 1x 6
- 5x 10
- 4x 6
- 2x 1 5x 5
- 2x 2 120 cm
- 2x 3
- 1x 4 20x 20x
- 2x 20x
- 2x 13x
- 1x 4x
- 4x 2x
- 2x 40 mm
- 1x 100 mm
- 1x 160 mm










22

23



24

25