


415 Schienenseilbahn / Cable Railway

LEVEL



- 2x
- 2x
- 2x

- 4x
- 2x
- 2x
- 2x
- 2x
- 2x
- 2x

- 2x
- 2x
- 2x
- 2x

- 1x
- 1x
- 7x
- 2x
- 1x
- 1x
- 2x

- 42x
- 1x
- 10x
- 2x
- 6x

130cm

Ax2

1

2

B

B

3

A

4


5

6


B

C


7




8



9




10




C


11




12




13




14








15




16



17



18



19

