



513 Berg-und-Tal-Karussell / Swing Ride

LEVEL




- 7x 1
- 6x 2
- 5x 3
- 3x 4
- 4x 5
- 2x 6
- 2x 7
- 2x 8
- 2x 9
- 2x 10
- 6x 30mm
- 4x 40mm
- 1x 160mm
- 3x 195mm
- 2x 1
- 4x 2
- 6x 3
- 2x 4
- 3x 5
- 2x 6
- 2x 10
- 6x 6
- 12x 19
- 1x 4
- 1x 6
- 6x 10
- 1x 25
- 1x 0
- 8x 1
- 7x 2
- 8x 3
- 2x 5
- 12x 4
- 1x 6
- 1x 6
- 1x 6
- 41x 41
- 29x 29
- 23x 23
- 48x 48
- 23x 23
- 16x 16
- 20x 20
- 16x 16
- 14x 14
- 13x 13
- 13x 13


A




1


















2




3











13


B




A 14





15



16




17




18


C




B 19



20




21





C

D



22

23




24


D

E x 2


25



26








27




F

E







29




30





31




F




32






33









34







35





40



41



42

